



816-12 Sash Jammer Fitting Instructions

Installing a Sash Jammer

To fit a Sash Jammer you will require the following tools:

- Drill
- Suitable drill bit
- Screwdriver

- A** Close window and select position of Sash Jammer on the outward opening frame.
- B** Drill pilot holes using sash jammer as template. Drill through the frame and the inside wall of the frame. If you encounter a reinforced steel or aluminium section, drill through that section carefully so as not to touch the glass.

Fix the Sash Jammer to the frame using suitable screws to ensure a tight fit.

- C** To ensure a tight fit select the correct size of button provided and fit underneath the lever, compress slightly (careful not to mark the PVCu frame).

Additional Information

Operation - Swing the lever over the fixed frame. Insert the locking part into the sash jammer and turn anti-clockwise to lock.

