



820-52 Window Staylocks Fitting Instructions

Installing a Window Staylock

To fit a Window Staylock you will require the following tools:

- Drill
- Suitable drill bit
- Screwdriver

- Remove existing pin and position Staylock(s) in place of existing stay peg(s). Use packing plate if necessary, then mark screw hole positions.
- Screw Staylock to fixed frame. Illustration shows packing piece for windows with a bevelled frame.
- Secure stay by screwing the locking nut down onto stay peg with key provided until tight.

Additional Information

Operation - Using key, turn anti-clockwise to remove locking nut and clockwise to secure.

Safety Tip - For child safety fit ERA Window Securistay Ref 720, to restrict full opening.

Security Tip - Always close and lock windows and remove key from locks when leaving the house. For extra protection we recommend using ERA Snaplock Ref: 801/802.

Maintenance - Use a moist cloth only, household abrasives or solvents may affect the surface finish - Lubrication may occasionally be required.

