



901-12 Metal Window Lock Fitting Instructions

Installing a Metal Window Lock

To fit a Metal Window Lock you will require the following tools:

- Drill
- 3.5mm drillbit
- Posidriv screwdriver
- Pencil

- A** Close window and select position of Metal Window Lock:
- ▶ Indicate lock position
 - ▶ Alternative positions for greater security
- B** Position lock mechanism on opening window frame. Leave a 3mm gap from the fixed window. Ensure clearance when opening the window, then mark screw holes.
- C** Apply masking tape to drill bit and drill holes to a 4mm depth.

CAUTION: Ensure that the drillbit does not touch the glass.

Screw the lock mechanism onto the frame.

Additional Information

Operation - Turn key clockwise and anti-clockwise to open.

Crime prevention tip - For extra security, drill out the drive slots in the screw head (we recommend fitting locks to top hinged windows).

Maintenance - Use a moist cloth only - household abrasives or solvents may affect the surface finish. Lubrication may occasionally be required.

